

401

405

the MCE counts the number of UEs which is in the active mode and receives the MBMS service 402 the number of the NO UEs is smaller than a threshold? YES 403 the MCE counts the number of the UEs which is in the idle mode and receives the MBMS service 404 NO the number of the UEs is smaller than a threshold? YES

suspend data transmission